














Knob Size Guide

Need a little help? Use this size guide to find the perfect fit for your kitchen.

While these size pairings provide a loose guideline based on the ratio between the knob and lid, ensuring a secure grip relative to the product's weight, you have the freedom to use our 45mm, 47mm, 55mm, 57mm, and various-shaped Cast Iron Lid Knobs on any size Casserole. Feel free to mix and match to your preference, and let your creativity soar

		
	45 - 47 MM	55 - 57 MM
 Round Casserole 18cm 20cm 22cm	✓	
 Round Casserole 24cm 26cm 28cm 30cm 34cm		✓
 Oval Casserole 25 cm	✓	
 Oval Casserole 27cm 29cm 31cm 33cm 35cm 40cm		✓
 Shallow Casserole 26cm 30cm		✓
 Rice Pot 18 cm	✓	
 Soup Pot 24cm 26cm 32cm		✓
 Risotto Pot 30cm		✓
 Saucepan 16 cm 18cm 20cm	✓	
 Bread Oven 24cm		✓
 Oblong 31cm		✓